



AIKO Design Ltd. Tel: 0191 296 4295

www.aiko-design.co.uk

Fitting Instructions- ZS & LS 2 bar sets for-

Vauxhall Astra (1998-2006 models)

Thank you for choosing **Aiko Design** roof bars – we aim to produce a no-nonsense product so all you will need to install your bars are some 10mm and 13mm spanners and a means to safely work at a comfortable height above your van without falling off.

Here is one of your brackets-



The brackets are slightly handed- it's not immediately apparent so to make life easier for you, you'll find a little notch in the edge of each one- these notches all need to be facing out over a corner of your van. The brackets are very easy to fit- when you get up on top of your vehicle you'll find some black plastic covers in the roof- these push down and slide open, revealing a vertical lip underneath.

The brackets clamp onto these lips with the M6 bolts and spring washers supplied; once the spring washer is flat and the brackets have stopped moving around, you're tight enough and good to go.

You can probably see what's coming next- lay your bars across the tops of your brackets, make sure you are happy that they are evenly positioned left and right, drop your strap over the top and do up the M6 fasteners.

Make sure that everything is secure and don't forget to give your rack periodic spanner-checks over the next week or so just in case it needs any settling down on the roof and that's it; we suggest a nice cup of tea at this stage.

Should you get stuck though please give us a call and we'll be happy to talk you through it and of course, don't forget to tell your mates where you got such a fabulous product!

Cheers!

Note- Please check your vehicle manufacturer's handbook for the maximum recommended roof load